

## FOR INSTALLATION PLEASE FOLLOW STEP #

1. FLIP BRACKET ① AND TIGHTEN BACK 1/4-20 HEX BOLTS.
2. ANCHOR BRACKETS TO FLOOR, PRE-DRILL HOLES. SEE FOOT PRINTS FOR REFERENCE. USE MAX. HOLE SPACING FOR INCREASED RACK STABILITY. ANCHORS NOT PROVIDED. ALL FRAMES MUST BE ANCHORED TO PREVENT TIPPING.
3. FASTEN STABILIZERS TO FRAMES.  
(2) 1/4-20X3/4L CARRIAGE BOLT  
(2) 1/4-20 KEPS NUTS  
TYP 2 SIDES
4. ADJUST SPACE BETWEEN FRAMES, TIGHTEN STABILIZER WITH  
(2) 1/4-20 KEPS NUTS  
TYP 2 SIDES.

STICKERS  
ON TOP

**NOTE DIRECTION OF  
FRAMES. CAGE NUT HOLES  
AND EIA MARKINGS  
FACING OUT**

